



SBH08-26

Pos.No.	Part No.	Description	Qty	Remark
1	5001814200101	Protection sleeve assembly	1	
1-1	5001814200102	Protective cap	1	
1-2	5001814200103	Snap ring	1	
1-3	5001814200104	Protection sleeve	1	
1-4	5001814100107	Thrust ring	1	
1-5	34401100101	Ball\ø7.14	1	
1-6	5001814200107	Holding plate	1	
1-7	5001814200108	Spring	1	
2	5001814200201	Screw\ST4.8x45	4	
3	5001814200301	Gear housing assembly	1	
3-1	5001814200302	Gear housing	1	
3-2	5001814200303	Oil seal\41x7x30	1	
3-3	5001814300304	Bushing assembly	1	
3-4	5001814200304	Needle bearing\HK3012	1	
3-5	5001814200305	Bearing bush	1	
3-6	5001814200306	Needle bearing\HK0608	1	
3-7	5001814200307	Ball bearing\628.2Z	1	
4	5001814300401	Selector knob assembly	1	
4-1	5001814200401	Red button	1	
4-2	5001814200501	Spring	1	
4-3	5001814100404	O-ring	1	
4-4	5001814200701	Selector knob	1	
5	5001814200801	Ratchet sleeve assembly	1	
5-1	5001814200802	Snap ring	1	
5-2	5001814200803	Washer	1	
5-3	5001814200804	Spring	1	
5-4	5001814200805	Cylindrical gear	1	
5-5	5001814200806	Pin	1	
5-6	5001814200807	Catch disc	3	
5-7	5001814200808	Snap ring	1	
5-8	5001814200809	Ratchet sleeve	1	
5-9	5001814100507	Oil seal\16x5x8.2	1	
5-10	5001814200811	Thrust ring	1	
5-11	5001814200812	Impact bolt	1	
5-12	5001814200813	Guide bushing	1	
5-13	5001814200814	O-ring	1	
5-14	5001814200815	O-ring	1	

SBH08-26

Pos.No.	Part No.	Description	Qty	Remark
5-15	5001814200816	Damping bushing	1	
5-16	5001814200817	Snap ring	1	
6	5001814200901	Cylinder assembly	1	
6-1	5001814200902	Piston	1	
6-2	5001814200903	O-ring	1	
6-3	5001814200904	Cylinder	1	
6-4	5001814200905	Shim ring	1	
6-5	5001814200906	Pin	2	
7	5001814201001	Intermediate flange assembly	1	
7-1	5001814201002	Bushing	1	
7-2	5001814201003	Intermediate flange	1	
7-3	5001814201004	O-ring	1	
7-4	5001814100705	Woolen cord	1	
7-5	5001814201006	O-ring	1	
7-6	35405900101	Ball bearing\609	1	
7-7	5001814201008	End shield	1	
7-8	34736100101	Screw\M4x10	1	
7-9	5001814201010	Washer	2	
7-10	35402700501	Ball bearing\627.2Z	1	
8	5001814201101	Shift assembly	1	
8-1	5001814201102	Guide rod	1	
8-2	5001814201103	Shift plate 1	1	
8-3	5001814201104	Shift plate	1	
8-4	5001814201105	Spring	1	
8-5	5001814201106	Shift plate 2	1	
9	5001814300901	Toothed shaft assembly	1	
9-1	5001814201202	Toothed shaft	1	
9-2	5001814201203	Clutch	1	
9-3	5001814201204	Wobble bearing	1	
9-4	5001814300905	Cylindrical gear	1	
9-5	35400600201	Ball bearing\607.2RS	2	
10	34714300101	Washer\ø4	1	
11	34795300101	Screw\M4x12	3	
12	5001814301201	Armature	1	
13	5001814301301	Air-deflector ring	4	
14	34728100201	Screw\ST4x16F	3	
15	5001814301501	Stator	1	
16	5001814201901	Rubber bearing sleeve	1	

SBH08-26

Pos.No.	Part No.	Description	Qty	Remark
17	5001814301701	Motor housing	1	
18	5001814101801	Brush holder base	2	
19	34727600501	Screw\ST4x12F	1	
20	5001814102001	Upper brush holder assembly	1	
20-1	5001814102002	Upper brush holder	2	
20-2	5001814102003	Brush holder	2	
20-3	5001814102004	Carbon brush	2	
20-4	5001814102005	Brush spring	1	
21	5001814102201	Inductor	1	
22	5001814202501	Switch	1	
23	5001814102301	Cord	1	
24	5001814102401	Cord guard	1	
25	5001814102501	Cord clip	1	
26	5001814102601	Housing cover	1	
27	34728700201	Screw\ST4.2x30C	2	
28	34728200301	Screw\ST4x18F	1	
29	5001814302901	Auxiliary handle assembly	1	
29-1	5001814102802	Clamping band	1	
29-2	5001814102803	T-bolt	1	
29-3	5001814102804	Clamp holder	1	
29-4	5001814102806	Clamp	1	
29-5	5001814102805	Compression spring	1	
29-6	5001814102807	Auxiliary handle	1	
29-7	5001814102808	Cap	1	
30	5001814102901	Depth gauge	1	